


OPC interface cables

SPI to USB (part # 000-0SPI-00)

This is the simplest solution if you wish to connect the OPC units with your PC and take the readings. You do not have to worry about the communication protocols or any extra equipment (power supply, cables) and no additional electronic engineering or programming knowledge is required.

The SPI can also help to verify your own set up as you can then compare both configurations.



For more information please see Application note 072-0501 (for OPC-R1), and 072-0503 (for OPC-N3)

Interface Cable Assembly (part # 000-CBLE-04)

If you wish to write your own communication program to drive the OPC, you can integrate this cable assembly into your own system. It comes complete with the connector, so no extra crimps are required.

